NANOTIME AFNOR

DESCRIPTION

The Nanotime time base sends local time by using AFNOR time code. It is synchronised by a GPS antenna which is provided with the product. It includes 67 time zones with automatic daylight saving time.

The AFNOR time distribution consists in transmitting a complete time message containing hour, minute, second, day, month and year to the clocks.

COMPLIANCE

• LVD 2014/35/EU, EMC 2014/30/EU, RED 2014/53/EU, RoHS 2015/863/EU directives.



OPERATING

Once the Nanotime is synchronised, the AFNOR output becomes active.

If the synchronisation is lost, the AFNOR output remains active.

After 24 hours without synchronisation, the synchro LED enters in search mode.

After a power failure, it is necessary to have the Nanotime synchronised for resetting the slave clocks.

A set of LEDs is used to verify the proper functioning of the product:

- Green LED indicating power supply.
- Red LED to check the status of the synchronisation.
- Red LED to check the status of the AFNOR output.

8 «TIME ZONE» DIP switches are used to set the local time.

The Nanotime automatically handles the daylight saving times.

These DIP switches can be set with the Nanotime switched on.

Two of these DIP switches are used to manually handle the daylight saving times:

- One is used to activate manual handling,
- Other one is used to set Winter or Summer time if manual handling is activated.

MECHANICAL FEATURES

• Dimensions	150 x 110 x 90 mm.
• Protection Index	IP 55, IK08.
Weight	0.6 kg.
Operating temperature	-20°C to +50°C.

ELECTRICAL FEATURES


• Synchronisation	GPS.
-------------------	------


• Accuracy...... 0.2s/day.

• Consumption...... 9.2W.

REFERENCES

• 927 281 NANOTIME GPS > AFNOR 100-240V





110

Dimensions in mm



